



Ember Quick Guide



SPECIFICATION

Dimensions	105mm H * 45mm D * 24mm W
Weight	115.8g
Oven Size	0.3g
Battery	2000mAh
Session Per Charge	18-20
Temperature Control Range	298°F-446°F Temperature Control Range



HOW TO USE

STEP 1

Push the cap and load the herbs into the chamber.



STEP 2

To turn the device on, press ▲ or ▼ button 5 times rapidly within 2 seconds. The device will vibrate for 0.5s when on.

STEP 3

The temperature can be set between 298°F and 446°F

There are two ways to adjust temperature:

Briefly tap on the ▲ or ▼ button to adjust the temperature respectively in 1-degree increments.

Hold the ▲ or ▼ button consistently to adjust the temperature quickly.



STEP 4

Dragonfly Ember starts heating to desired temperature setting in 20 seconds.

STEP 5

The unit will vibrate for 0.5 seconds when you reach your selected temperature. The 🌀 symbol indicates that the device is ready to use.

STEP 6

To turn the device off, press ▲ or ▼ button 5 times rapidly within 2 seconds. The device will vibrate for 0.5s when off.

IN THE BOX



DRAGONFLY EMBER



USB Cable



Cleaning
Brush



Packing
Tool



3xSS Screen
for Chamber



2xSS Screen
for Mouthpiece





Quick Guide



Temperature Guide

CHARGING

- The device contains an internal 2000mAh Lithium-Ion battery. Do not destroy the cover and take the battery out.
- Charger input voltage: DC5V1A/2A
- Initially charge the Dragonfly Ember for 2.5 hours. The battery will stop charging automatically when the icon shows full.
- When the battery level is low, charge battery with Type-C USB cable.
- Charging the Dragonfly Ember while power on, the OLED display will stay lit with the full battery icon. "  " means a full charge.
- Charging the Dragonfly Ember while power off, only the full battery icon will be visible. "  " means a full charge.
- Do not use the Dragonfly Ember while charging. This will cause damage to the device.
- To prevent the device from overheating, do not leave the charger plugged in overnight.
- Use only the charger provided. Do not use a damaged or non-Dragonfly Ember charger. Incompatible chargers may carry different voltage, which may be a fire hazard.

MEMORY FUNCTION

The device features a smart memory function. It will memorize the data of current use before powering off. When powered on for next use, the last setting will be displayed.

WARNINGS

- Do not drop, deform, bend, crush, puncture, incinerate, microwave, shred, paint or insert foreign objects into Dragonfly Ember.
- Do not attempt to repair or modify the Dragonfly Ember.
- Use caution when handling Dragonfly Ember. The heating chamber area is hot when the device is powered on. Refrain from direct contact with the main heating chamber when hot. Do not leave the device unattended when it is powered on or while the device is still hot.
- Failure to do so will void the limited warranty offered on Dragonfly Ember.
- This device is intended for adult use and consumption only. Keep this booklet in a safe place for future reference.

WARNINGS

This device is designed as a mobile solution for the practitioners of aromatherapy and should be used for dry herbal blends as indicated. This device is not intended for use with illegal substances.

CHOKING HAZARD

The Dragonfly Ember contains small parts which may be a choking hazard to small children. Please keep device away from children.

